#### 1. Usage and storage instructions

Do not expose the product to humid environments or extreme temperatures, it could be damaged. If water enters by accident stop the operation to prevent a short circuit. Do not use our product more often or for a longer period than traditional cigarettes. Keep the product out of the reach of children, adolescents and pets.

When using liquids with and without nicotine: Please note the warnings and instructions for use of the liquid products and do not mix them with other substances. Do not use the product if you have a known problem with nicotine or other liquid ingredients. In case of nausea, dizziness or rash, discontinue use and consult a medic immediately. The electronic cigarette is not for smoking cessation.

Delivery to and use by children and adolescents under the age of 18 is prohibited. The product is not recommended for non-smokers

This product is not suitable for pregnant women, women who are breastfeeding, people with cardiovascular and respiratory diseases, alcoholics and epilentics. Do not use the product if you have lung disease (such as asthma, COPD, bronchitis, pneumonia). The released vapor may cause an asthma attack, shortness of breath and coughing fits in the case of a previously damaged lung. If complaints occur, please seek medical attention immediately. Do not use our product if you have a known problem (allergies, intolerances, etc.) with nicotine or other ingredients of our product.

When using nicotine-containing liquids: nicotine-containing products are not suitable for people who, for medical reasons, should abstain from nicotine products. If the liquid is swallowed, contact the emergency number. You can also contact the poison emergency service in your area.

#### 4. Information on possible adverse health effects

- none known, see the instructions of the liquid

#### 5. Information on addictive effects

If you use products containing picotine, the following warning is displayed on the packaging of the liquids: "This product contains nicotine: a substance that is highly addictive.

### 6. Information on toxicological data

Overheating the liquid (over 240 \* C) in the electronic cigarette may cause toxicological substances. Please use the electronic cigarette according to the manufacturer's recommendation and operating instructions. The use of this product is at your own risk

#### 7. Contact

If you need additional information or if you have questions about the products and their use, please contact our local shops or visit our website: www.smokerstore.de



SmokerStore GmbH Fisenwerkstraße 26 58332 Schwelm, Deutschland Email: info@smokerstore.de Tel.: +49 (0)2336 / 935899-0 Fax: +49 (0)2336 / 4744870













### LOWER COTTON CHAMBER OF BASE

The base has its own cotton chamber. This serves as an additional buffer and perset oversaturation of the upper cotton chamber. The amount of control needed, deposits on the type of the chamber. The amount of control needed, deposits on the type of the deposits of the control needed, deposits on the type of the deposits of the deck and base, to be used particularly all registers and a higher underpressure (see to the perfected pull feature) if a made seems to insent the verificiant of the six and to use once to other behavior if a migrating must have been control under the verificiant of the six and to use once to other behavior if an improving must "hereby the deck and the position and the six and the position of the six and the seems to destine the verificiant of the six and to use once to other behavior is an improving must "hereby the deposition" and the position of the six and the seems to the six and the seems to the six and the seems to destine the six and the six and the seems to the six and the se



Taifun





By removing the positive pole screw, the deck and base can be separated without removing the coil (e.g. when changing the wicks or converting the tank from 4ml to 2ml).

COTTON CONTACT BETWEEN BASE AND DECK

Always make sure that the tank is filled sufficiently to avoid dry hit.

Make sure that no liquid gets on your skin, otherwise wash these areas thoroughly.

When the tank is overfilled, liquid can escape from the vent hole and lead to permanent liquid moisture on the MF Ring.

#### 1. PRODUCT DESCRIPTION SCOPE OF DELIVERY

1x Taifun® GX 1x Spare Parts Bag 1x Drip Tip 2x Steel Rope 7x7 1x Allen Key 1 3 mm 1x Allen Key 2,0 mm 2x Mesh Stripes



# Stainless Steel (1.4301) / Borosilicate Glass / PEEK / POM

#### 2. SAFETY INSTRUCTIONS

- Do not expose the device to extreme temperatures; Avoid exposure to direct sunlight and high humidity.
   Do not use the device in an environment that is enriched with flammable gases, vapors or dusts; There is a danger of explosion!
- Do not drop, throw, or apply excessive force to the device to prevent damage; Do not use the device if you detect damage.
- Refill the liquid early to prevent dry hit
- The device heats up during use; give it time to cool down again.
- Change the cotton, if you change the flavour.
- Clean the device regularly, as condensate and dirt may settle.

  Make sure that the mod that you use with the device is capable of performance; use of mods without protection is

#### 3. MANUFACTURER RECOMMENDATIONS

- The resistance of the used coil should not be less than 0.3 Ohms
- Adjust the power of your mod to an appropriate level, depending on the used coil.

### 4 STORAGE INSTRUCTIONS

- If you don't use the device for an extended period of time, close the airflow control or empty the tank, remove the cotton and clean the device
- Keep the device out of the reach of children and pets Ensure that the device is firmly and securely in place.
- Store the device clean and dry: avoid high humidity
- Do not store the device under extreme temperatures; avoid exposure to direct sunlight.

#### 5. DISPOSAL NOTICE

- The packaging must be disposed of in an environmentally friendly manner.
- Products marked with the crossed out bin, do not belong in the trash. These products can be disposed of free of charge in your local trade or at community collection points. Check with your local council, town hall or local waste management company

#### AUTHENTICITY VALIDATION

You can check the authenticity of your Taifun product at www.taifun-check.com.
You can find the verification code and the serial number on your device: 12345678911-1234 (verification code - serial number)

## Taifun

# SMOKERSTORE &

### ADJUSTING THE MF RING / VENTILATION

side of the MF ring there are grooves that serve for ventilation when vaping and ven with additional tank ventilation and without.

Depending on the liquid, the power used and your own puff behavior, adjustment via the MF ring is possible. With a higher VG content of the liquid and / or higher performance, the tank must be vertilated via the ring. To do this, turn the ring closuble (batting from the closed position). When the clock airliow is opened to the maximum, the ring stoke the Print globes or tamps in high position and the symbiol for tank vertilation CNV is visible in the closural reasons. In

Execute verificion of the texts is guaranteed even with Intend afters. Expositely with higher draw meisterness place options at it delay and or the use of details.

Applied (SSIVIO in higher PC controll I may be incomes jor solated from the execute verification of the texts. The eventillator of the texts in the revisitation of the texts in the revisitation of the texts in the revisitation of the super controllator out of the light from the text in the revisitation of the super character controllator. Our of the light from the text is also revisitation of the super character is the propose to the revisitation of the super character is also reported to the verification of the super character is exposed to the verification of the super character is an exposed to the verification of the super character is a super part to place and the provide for the verification of the super character is an exposed to the verification of the super character is an exposed to the verification of the super character is a super part to place and the provide for the verification of the super character is an exposure of the super part to place and the provide for the verification of the super character is an exposure of the super part to place and the provide for the verification of the super character is an exposure of the super character is a super character in the super character is an exposure of th

In order to preside the deck addition, the rings must be related fafter counter obsisions until a dange the rings than those ord array, into place (b). We the beneath resultation of the trials in excluded, even with his final darken expedition. The counter of the VER by counting depends on open comparement is however, and the dark of the draw resistance is preferably low with high VG lagst and higher prover, the rings is turned clockwise to be to tap and with higher draw resistance of CR (Dalgst and routine prover. The rings is turned controlled to the counterpart of the opening instruction feeting free orders used).

Afternatively, an optional base with entanged holes for increased verifiation and easier filling with way high Viccontaining labels as landles expension. It is a satisfied setting upon and offers no option to seatch off the optional transit verification during operation. With the optional base the ring cannot be furned contracteduction on while filling operating.

IMPORTANT

The MR Ring is <u>not</u> a classic AFC Ring for air flow control. The airflow can be regulated to a limited extent via the MF Ring, but the actual airflow regulation takes place via the Air Disk used in the Deck.





#### OPTIONAL (ADDITIONAL) VENTILATION


Some setups require additional ventilation, for example for extreme performance. In this case the he removed. However, removal means that the atomizer may no longer be able to be stored lying down

### AIR FLOW REGIJI ATION VIA AIR DISK

The air flow is controlled by the Air Disks installed in the base. They regulate and center the airflow directly to the coil. Air Disks with 3 x 1.8 mm holes are included in the scope of delivery. For more or lesser restrictive drawing resistance, optional Air Disks are available from retailers. To remove the Air Disk (e.g. when changing), it is recommended to reach into the small notch on the outside with a pointed tool and slide the Air Disk up and out.







SMOKERSTORE >





SMOKERSTORE &

5 x Hexagon Socket Screws (M2.5 x 4)





O



2x O-Ring (NBR 70 17x1 mm)



1x Isolator Positive pole screw



#### IMPORTANT The device is deli mbled. All O-Rings and isolators are already installed correctly. This list is only for illustration and

possible assembly after cleaning the individual parts.
A stainless steel ball is attached to the base (D). It is used to snap the MF Ring into the respective positions

## Taifun



### 8. CLEANING

Do not use cleaning agents as they could harm the O-Rings Before assembling, check the completeness and positioning of the O-Rings to prevent leakage of liquid.

Disassemble the device into its components.

- Clean the components (not the cotton) with warm water or in an ultrasonic bath. Completely dry the components before reassembling the device.

### 9. MAINTANANCE

- Wait until the device has completely cooled down before disassembling, to prevent burns.
- · Make sure that there is no power supply by unscrewing the device from the mod or by switching off the mod. ASSEMBLING DEVICE The device is usually delivered fully assembled, the following instructions are for the assembly after cleaning.
- Moistening the sealing rings with liquid makes the assembly easier. Please use only suitable tools for assembly.





The O-Ring (O), O-Ring (N) and O-Ring (M) will be attached to the Base (D).



The two Air Disks (H) are pushed into the Base (D).

The Ball (S) ensures a stable hold there.

Taifun



#### 7. START UP

#### ATTACUING THE STEEL DODES

INTERVITATION

The two C-Rings attached to the Steel Ropes serve to hold the Steel Ropes together. Never remove both O-Rings at the same time, otherwise the Steel Rope will fall apart. Instead of the Steel Ropes you can also use the included Mesh Strips.

The upper O-Ring also has the function of sealing the base from the tank.





SMOKERSTORE &







Use an ohm mater to check the resistance of the colidering

before using it. Don't use the device, if a short circuit is de Chack if there is a contact between the coil ends and the

## Taifun

ATTACHING A COIL









#### REPLACING THE TANK GLAS

If the Tank Glass is damaged or broken, it must be replaced.

Only use original spare parts, which can be obtained directly from www.smokerstore.de or from authorized

. Before replacing the Tank Glass, the atomizer must be completely emptied

#### REPLACING SEALING RINGS

Sealing rings are used to seal the device. . If you notice liquid or moisture leaking out of the device, the cause may be brittle seal rings that need to be

Moistening the sealing rings with liquid makes the assembly easier.

A comprehensive guide can be downloaded online at www.smokerstore.de as a PDF. See also QR code on page 1





If you have further questions about attaching a coil and the individual settings of the device, please contact your





